ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0327 **ING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements. 2. READ AND SAVE THIS INSTRUCTION. Outlet Box

	Hardware Pa	ackage (included	:(k	Wire Connector (F)				
			a				nd Screw (C)	
			e			Mounting St	rap (A)	
	Mounting Strap (A)	Mounting Screw (B)	Green Ground Screw (C)			Lock Nut (D)		
	66					Strain Relief		
	Lock Nut (D)	Fixture Mounting Screw (E) Wire Connector (F)				(-)	
						Canopy Hex Nut		
		$\bigcirc \bigcirc$			ت المرفر	Ball Nut (H)	d(3/8")	
	Strain Relief (G)	Ball Nut (H)	Flat Head Screwdriver (I)			Plastic Headless		
 Ir	stallation Ste	eps				Screw	c(3") ↓	
		at fuse or circuit box				Cord (a)		
			-			Fixture Wire		
1.	Unscrew two ball	nuts (H), remove mo	ounting strap (A) from car	пору.	Ĩ		b(9")	
	Loosen the plasti screw driver (I) .	c headless screw on	the canopy by using flath	nead				
	desired length of leave additional §	the cord (a) from the	and strain relief (G). Mea e canopy to the glass sha canopy (include the car I. (See Fig.1)	ade and				
4.	Adjust strain relie	f (G) at 9" position fr	om the top of the cord.				Fig.1	
	to peel off the ins 3 inside wires ou Caution : Cuttin	sulation of the cord (c ut. (See Fig. 1) g too deep may cut	e cord (b). Use a knife c) carefully to show the c off three inside wires of the three inside wire	95.				
	Peel off the 3 wire the copper for wire	•	t 3/8" long (d) to expose			Glass Shade		
	Attach the mountin screws (B).	ng strap (A) to outlet l	box by using two mountin	g				
	using wire connect a. Connect the bla from the power b. Connect the wh from the power c. Connect the co to the mounting The green grou ground wire fro	ctors (F) as follows: ack wire marked "L" f r source. nite wire marked "N" fi source. pper wire or green wing strap (A) by securing	t box. Make wire connect rom the fixture to the blac rom the fixture to the whit re marked "⊕" from the f g it with the green ground from the fixture to the gree	ck wire e wire fixture screw.		Medium Base E Max.60W (not i		

191205

Carefully put wires back into the outlet box.

- 9. Pull the cord (a) down slightly until the strain relief (G) touches the hex nut. Attach two fixture mounting screws (E) to the mounting strap (A), then secure it with two lock nuts (D). Adjust the length of the fixture mounting screws (E) if necessary, then secure it with two ball nuts (H).
- 10. Fastening cord by screwing plastic headless screw, using flat head screwdriver (I).
- 11. Install a bulb (not included). Check relamping label at socket area or packaging for maximum allowed wattage.

Turn on the power at fuse or circuit box.

The following parts are available for re-order if damaged or missing.

Spare Parts Lis	<u>t:</u>			
	(f. juning) (f. juning)	Ŷ		
Mounting Strap (A)	Mounting Screw (B)	Green Ground Screw (C)		
66	(Common)		Assembly Kit 6162MM (1 SET)	
Lock Nut (D)	Fixture Mounting Screw (E)	Wire Connector (F)		
Strain Relief (G)	D Ball Nut (H)	Flat Head Screwdriver (I)	Glass Sh X1 10118LF	ade



